



GETTING STARTED


Note: For further information, please refer to the User Guide included in the Installation CD




The package includes:
CD, PC Adapter, DisplayDock
(Device Adapter + Docking
Base), and power supply.




Insert the CD and install
software drivers (A new gray
icon appears in system tray).




Plug the PC Adapter to a
USB port on your PC (Tray
icon turns red).



For vertical mounting:
Place the DisplayDock on a
vertical surface (rear side of
monitor, wall).



For table top positioning:
1. Remove Device Adapter from
Docking Base.
2. Slide shutter to show top
USB port.
3. Re-attach Device Adapter.




Connect the DisplayDock to your
monitor, speakers, keyboard and
mouse. Connect the power cable
(Tray icon turns green, display
icon is on). You're done!

Quick Tips for Best Performance


Playing video from your PC?

1. Use Extend Mode, and limit the extended screen resolution to 720p (1280x720).
2. If available it is recommended to use Optimize for Video Mode.



Streaming video from the internet (e.g. Youtube)?

Make sure to Disable Hardware Acceleration on your Flash Player.



Using Windows Vista?

Use the AERO Desktop Theme.

Problems?

Right-click the Wireless USB Manager taskbar icon and select Help, or see Troubleshooting in the User Guide (available on the installation CD).